




# TV Unit Etana 1500x1500x300 mm

## ASSEMBLY INSTRUCTION



### To avoid falling

we recommend fixing the product to the wall using **corners** or **double-sided tape**

Purchase separately.

### Dimensions

Height: 1500 mm

Width: 1500 mm

Depth: 300 mm



### **NOTE!**

For all questions and complaints about this product, please contact the place of purchase of this product.






## **RULES FOR USE AND CARE OF FURNITURE**

1. Use furniture only in dry rooms protected from the effects of weather conditions.
2. Install with suitable tools according to these assembly instructions.
3. Try to assemble as close to the location as possible.
4. The body is assembling in a horizontal position.
5. Before moving furniture, make sure that it is not loaded with items.




**Caution:** moving furniture may damage it.

When moving, hold on to vertical elements only; moving furniture by horizontal parts can break the product.


6. Overloading the furniture can damage it.
7. From time to time check the fittings and their correct position.
8. Wipe the furniture surface only with a slightly damp cloth or paper towels. Do not use chemical cleaning agents other than those specifically made for this.



60-120 min 




# PARTS LIST




Nº	Description	Dimensions	Nº pack	Qty.	Nº	Description	Dimensions	Nº pack	Qty.
1	STAND	900 300	1	1	6	IN.STAND	200 284	1	1
2	S.R.STAND	416 300	1	1	7	L.S.STAND	1484 220	1	2
3	BOTTOM	1500 300	1	1	8	B.WALL	1086 416	1	1
4	S.TOP	1102 300	1	1	9	SHELF 2	350 220	1	4
5	SHELF	559 284	1	1	10	S.D.STAND	200 284	1	1



## Fittings:





1





2




3



4



5



6

